

## Product Datasheet

**Product code:** **EX410**

**Product type:** Micro-shears and Micro-pliers

**Made in:** USA

**Description:** EX410 is a micro shear flush cutter. Size and shape are optimized to work in high density areas. Its shears employ a unique technology to carry out a clean and smooth cut. Providing this cutter with anti-shock shear cut features, in fact, this system greatly reduces mechanical shock to the component and requires the operator less effort to perform the cut. The shears are equipped with an ESD Ergo-tek handle which allows an excellent grip, suitable to environments and to components susceptible to electrostatic discharges.

**Head description:** Micro, Shear

**Cutting edges:** Flush

**Cutting capacity:** soft wire 1.02 mm (18 AWG)

**Body material:** Carbon Steel (C)

**Handle material:** TPE + PP

**Picture:**



<b>Dimensions:</b>	OAL (A)	127.0 mm – 5.000 inch
	Width	48.0 mm – 1.890 inch
	Height	13.0 mm – 0.512 inch

<b>Head dimensions:</b>	Width (C)	14.0 mm – 0.551 inch
	Thickness (D)	6.4 mm – 0.252 inch
	B	9.0 mm – 0.354 inch