

Product Datasheet

Product code: **EX2175**

Product type: Micro-shears and Micro-pliers

Made in: USA

Description: EX2175 is a maxi-shear flush cutter with enough toughness to cut harnesses and cables, and the precision to cut material with less than 1-millimeter thickness or to work in high density areas. Its shears employ a unique technology to carry out a clean and smooth cut. Providing this cutter with anti-shock shear cut features, in fact, this system greatly reduces mechanical shock to the component and requires the operator less effort to perform the cut. The shears are equipped with an ESD Ergo-tek handle which allows an excellent grip, suitable to environments and to components susceptible to electrostatic discharges.

Head description: Maxi, Shear

Cutting edges: Flush

Cutting capacity: soft wire 2.00 mm (12 AWG)

Body material: Carbon Steel (C)

Handle material: TPE + PP

Picture:



Dimensions:	OAL (A)	150.0 mm – 5.906 inch
	Width	53.0 mm – 2.087 inch
	Height	13.0 mm – 0.512 inch

Head dimensions:	Width (C)	17.0 mm – 0.669 inch
	Thickness (D)	3.0 mm – 0.118 inch
	B	12.0 mm – 0.472 inch